


MACHEREY-NAGEL

# User manual












■ NucleoSpin® gDNA Clean-up XS

November 2023 / Rev. 07

# Genomic DNA clean-up

## Protocol at a glance (Rev. 07)

### NucleoSpin® gDNA Clean-up XS

1 Prepare sample		Adjust up to 400 µL aqueous sample with buffer TE to 800 µL
2 Adjust DNA binding conditions		200 µL NT
3 Bind DNA	 	Load 500 µL diluted sample 11,000 x g 30 s  Load remaining sample 11,000 x g 30 s
4 Wash silica membrane	 	Turn spin cup inside the centrifuge by 180° compared to the loading position  100 µL B5 11,000 x g 2 min
5 Elute DNA	 	1. 6–15 µL BE 11,000 x g 1 min  2. 6–15 µL BE 11,000 x g 1 min
6 Removal of residual ethanol and concentration		90 °C 8 min (2 x 10 µL elution) or 5 min (10 µL elution)

## Table of contents

1	Components	4
1.1	Kit contents	4
1.2	Reagents, consumables, and equipment to be supplied by user	4
1.3	About this user manual	4
2	Product description	5
2.1	Basic principle	5
2.2	Kit specifications	5
2.3	Handling of sample material	7
2.4	Elution procedures	7
2.5	Concentration and removal of residual ethanol	8
3	Storage conditions and preparation of working solutions	9
4	Safety instructions	10
4.1	Disposal	10
5	NucleoSpin® gDNA Clean-up XS protocol	11
6	Appendix	13
6.1	Troubleshooting	13
6.2	Ordering information	14
6.3	Product use restriction / warranty	15

# 1 Components

## 1.1 Kit contents

NucleoSpin® gDNA Clean-up XS			
REF	10 preps 740904.10	50 preps 740904.50	250 preps 740904.250
Binding Buffer NT	25 mL	25 mL	75 mL
Wash Buffer B5 (Concentrate)*	6 mL	6 mL	6 mL
Elution Buffer BE**	13 mL	13 mL	13 mL
NucleoSpin® gDNA Clean-up XS Columns (light green rings)	10	50	250
Collection Tubes (2 mL)	30	3 × 50	3 × 250
User manual	1	1	1

## 1.2 Reagents, consumables, and equipment to be supplied by user

### Reagents

- 96–100 % ethanol
- Buffer TE (e.g., 10 mM Tris/HCl pH 7.5, 0.1 mM EDTA)

### Consumables

- 1.5 mL microcentrifuge tubes (for sample lysis and DNA elution)
- Disposable pipette tips

### Equipment

- Manual pipettors
- Thermal heating block
- Centrifuge for microcentrifuge tubes
- Personal protection equipment (lab coat, gloves, goggles)

## 1.3 About this user manual

It is strongly recommended that first-time users of the **NucleoSpin® gDNA Clean-up XS** kit read the detailed protocol sections of this user manual. Experienced users, however, may refer to the Protocol-at-a-glance instead. The Protocol-at-a-glance is designed to be used only as a supplemental tool for quick referencing while performing the purification procedure.

All technical literature is available on the internet at [www.mn-net.com](http://www.mn-net.com).

## 2 Product description

### 2.1 Basic principle

The **NucleoSpin® gDNA Clean-up XS** kit is designed for a fast and convenient purification of genomic DNA from aqueous samples (e.g., phenol / chloroform extracts). PCR inhibitors (e.g., indigo) are efficiently removed and DNA is concentrated with high recovery. Due to its high sensitivity the kit is particularly well suited for trace levels of DNA from forensic samples. The optimized protocol allows for up to 400 µL of aqueous sample to be processed without the need for error-prone repeated loading steps. However, multiple loading steps can be used without difficulty to process larger sample volumes. The special funnel design of the thrust rings inside the **NucleoSpin® gDNA Clean-up XS Column** in combination with the very small membrane allows for high recovery with very small elution volumes (5–30 µL) which results in highly concentrated DNA.

Appropriate conditions under which DNA binds to the silica membrane are created by addition of Binding Buffer NT. The mixture is then applied to the **NucleoSpin® gDNA Clean-up XS Column** and the DNA binds to a silica membrane. A subsequent washing step efficiently removes contaminations and highly pure DNA is finally eluted with 5–30 µL of a slightly alkaline elution buffer of low ionic strength (5 mM Tris/HCl pH 8.5).

### 2.2 Kit specifications


- The **NucleoSpin® gDNA Clean-up XS** kit is recommended for the purification and concentration of genomic DNA from very dilute aqueous samples. Typical sample materials comprise for example PCR inhibitor containing solutions, Proteinase K reaction mixtures, or the aqueous phase of phenol / chloroform extractions.
- The robust membrane allows for multiple loading steps to process even large sample volumes.
- The special column design and the very small membrane lead to a significantly reduced dead volume which allows for high recovery of small amounts of DNA with as little as 5–30 µL elution buffer.
- DNA is ready-to-use for all common downstream applications like (e.g., real-time PCR).
- The preparation time is approximately 20 min for 6–12 samples.

**Table 1: Kit specifications at a glance**

Parameter	NucleoSpin® gDNA Clean-up XS
Sample material	< 400 µL solution containing < 2 µg DNA
Typical recovery	60–70 %
Fragment size	100 bp–approx. 50 kbp
$A_{260}/A_{280}$	1.8–1.9
Elution volume	6–15 µL
Preparation time	20 min/6 preps (exclusive preceding extraction or lysis)
Format	Mini spin column – XS design
Use	For research use only

- **Forensic quality product:**

**NucleoSpin® gDNA Clean-up XS** is certified as forensic quality product. Consumables used in forensics need to be treated carefully to prevent DNA contamination. MACHEREY-NAGEL therefore has a stringently controlled production process to avoid DNA contamination of consumables. Further, MACHEREY-NAGEL uses ethylene oxide (EO) treatment to remove amplifiable DNA, which might still be introduced during the manufacturing process. MACHEREY-NAGEL products carrying the forensic quality seal, contain plastic materials that are EO treated. This means, DNA of any kind, which might still be introduced into plastic consumables during the production process, is inactivated by means of the treatment with ethylene oxide, in order to prevent the generation of accidental human profile by PCR amplification. Ethylene oxide treatment has been shown to be the method of choice to prevent DNA profiles due to DNA contamination (Shaw et al. 2008; Figure 1).



**Figure 1** According to Shaw et al., 2008, Comparison of the effects of sterilization techniques on subsequent DNA profiling. *Int J Legal Med* 122: 29–33.

## 2.3 Handling of sample material

The **NucleoSpin® gDNA Clean-up XS** procedure is designed for very small amounts of genomic DNA and the typical downstream applications are thus very sensitive. It is consequently highly recommended to perform sampling and DNA purification with special care, in order to avoid a contamination of the sample or the purified DNA with unwanted DNA-containing material (e.g., fingerprints, hair particles, aerosol, dust).

Moreover, a cross-contamination between samples has to be excluded. The following precautions are recommended:

- Wear personal protection equipment (lab coat, gloves, goggles).
- Use aerosol resistant pipette tips.
- Always change pipette tips between liquid transfers.
- Briefly centrifuge after mixing steps in order to remove droplets from tube lid.

## 2.4 Elution procedures

A high DNA concentration in the elution fraction is of importance and desirable for all typical downstream applications. This is of particular interest if the total volume of a reaction mixture is limited as this in turn limits the possible amount of DNA that can be added. Due to a high default elution volume, classical DNA clean-up kits often result in weakly concentrated DNA, if only small amounts of DNA are processed.

Such DNA may even require a subsequent concentration before it can be used for typical downstream applications.

In contrast to classical kits, **NucleoSpin® gDNA Clean-up XS** allows for efficient elution in a very small volume which results in highly concentrated DNA.

For forensic samples elution with  $2 \times 6 \mu\text{L}$  is recommended to maximize concentration and yield. A two-fold elution generally yields more DNA than just one elution with the same total buffer volume. Optionally, the second elution can be omitted to achieve the highest possible DNA concentration.


In general, larger volumes (10–30  $\mu\text{L}$ ) increase the overall DNA yield but naturally reduce the final DNA concentration. Elution buffer volumes  $> 30 \mu\text{L}$  will only slightly increase total DNA yield.

## 2.5 Concentration and removal of residual ethanol

For most applications removal of trace levels of ethanol is not required. However, if a large volume of eluate has to be used as PCR template a heat incubation of the eluate is recommended. An incubation of for example 8 min at 90 °C for a 20  $\mu\text{L}$  eluate removes residual ethanol in the eluate and concentrates the DNA to approximately 11  $\mu\text{L}$  resulting in a significantly increased sensitivity in downstream applications. The template may then represent up to 40 % of the total PCR reaction volume. The necessity of this step may be individually tested.

An incubation at 90 °C, however, will denature DNA. If non-denatured DNA is required for downstream applications other than PCR (e.g., ligation or cloning) we recommend an incubation of 17 min at 75 °C to remove ethanol from an eluate of 20  $\mu\text{L}$ .

Even if ethanol is of no concern for the downstream application the heat incubation is a useful means to concentrate an eluate. Use Figure 2 to estimate the necessary incubation time depending on your elution volume and the intended final volume. Take into consideration that incubation times may vary depending on the heating block or microcentrifuge tubes that are used. Shaking the tubes during incubation increases the evaporation rate even more.



**Figure 2 Concentration and removal of residual ethanol from eluates by heat treatment.** Eluates of 10, 20, and 30  $\mu\text{L}$  were incubated at 75 °C (non-denaturing) and 90 °C (denaturing) for 0–40 min without shaking. Choose your final volume and read the necessary incubation time from the appropriate curve. For other starting volumes just interpolate the array of curves.



### 3 Storage conditions and preparation of working solutions

*Attention:*

Buffer NT contains guanidinium thiocyanate. Wear gloves and goggles!

Storage conditions:

- All kit components can be stored at 15–25 °C and are stable for at least one year.

Before starting any **NucleoSpin® gDNA Clean-up XS** protocol prepare the following:

- **Wash Buffer B5:** Add the indicated volume of ethanol (96–100 %) to **Buffer B5 Concentrate**. Mark the label of the bottle to indicate that ethanol was added. Wash Buffer B5 can be stored at 15–25 °C for at least one year.

NucleoSpin® gDNA Clean-up XS			
REF	10 preps 740904.10	50 preps 740904.50	250 preps 740904.250
Wash Buffer B5 (Concentrate)	6 mL Add 24 mL ethanol	6 mL Add 24 mL ethanol	6 mL Add 24 mL ethanol

## 4 Safety instructions

When working with the **NucleoSpin® gDNA Clean up XS** kit, wear suitable protective clothing (e.g. lab coat, disposable gloves, and protective goggles). For more information, consult the appropriate Material Safety Data Sheets (MSDS available online at <http://www.mn-net.com/msds>).



Caution: Guanidinium thiocyanate in Buffer NT can form highly reactive compounds when combined with bleach! Thus, do not add bleach or acidic solutions directly to the sample preparation waste.

The waste generated with the **NucleoSpin® gDNA Clean up XS** kit has not been tested for residual infectious material. A contamination of the liquid waste with residual infectious material is highly unlikely due to strong denaturing lysis buffer treatment, but it cannot be excluded completely. Therefore, liquid waste must be considered infectious and should be handled and discarded according to local safety regulations.

### 4.1 Disposal

Dispose hazardous, infectious or biologically contaminated materials in a safe and acceptable manner and in accordance with all local and regulatory requirements.

## 5 NucleoSpin® gDNA Clean-up XS protocol

Before starting the preparation:

- Check if Wash Buffer B5 was prepared according to section 3.
- Prepare buffer TE (e.g., 10 mM Tris/HCl pH 7.5, 0.1 mM EDTA)

### 1 Prepare sample

*Note:* The following dilution step with TE buffer might not be necessary for highly concentrated samples, for uncomplicated pre-purified DNA, or non-forensic samples.

For < 400  $\mu\text{L}$  sample solution, dilute with **buffer TE** (not provided) to a **final volume** of **800  $\mu\text{L}$** .

For > 400  $\mu\text{L}$  sample solution, add 1 vol of **buffer TE** and increase Buffer NT proportionally in step 2.

Mix thoroughly by vortexing and spin down briefly to clear the lid.



+ TE  
to a final  
volume of  
800  $\mu\text{L}$

### 2 Adjust DNA binding conditions

Add **200  $\mu\text{L}$  Buffer NT** per **800  $\mu\text{L}$  diluted or undiluted sample** (e.g., add 100  $\mu\text{L}$  Buffer NT to 400  $\mu\text{L}$  sample).

Mix thoroughly by vortexing. Spin down briefly to clear the lid.



+ 200  $\mu\text{L}$  NT  
per 800  $\mu\text{L}$   
of sample


### 3 Bind DNA

For each sample, place one **NucleoSpin® gDNA Clean-up XS Column** into a **Collection Tube (2 mL)**.

Add 500  $\mu\text{L}$  of binding mixture to the column. Centrifuge for **30 s** at **11,000 x g** and discard the flow-through.

Add the remaining binding mixture to the column and centrifuge for **30 s** at **11,000 x g**.

Place the column into a new **Collection Tube (2 mL)**.



Load 500  $\mu\text{L}$   
sample

11,000 x g  
30 s

Load remaining  
sample

11,000 x g  
30 s

### 4 Wash silica membrane

Turn the NucleoSpin® gDNA Clean-up XS Column inside the centrifuge by 180° compared to the loading position in order to allow optimal washing efficiency.

Add **100  $\mu\text{L}$  Buffer B5**.

Centrifuge for **2 min** at **11,000 x g**.



+ 100  $\mu\text{L}$  B5



11,000 x g  
2 min

## 5 Elute DNA

Place the NucleoSpin® gDNA Clean-up XS Column into a 1.5 mL microcentrifuge tube (not supplied).


Add **6–15 µL Buffer BE** directly to the center of the membrane.

Centrifuge for **1 min** at **11,000 x g**.

Add another **6–15 µL Buffer BE** directly to the center of the membrane.

Centrifuge for **1 min** at **11,000 x g**.


*Note: The elution volume can be varied from 5–30 µL. The second elution step can be omitted leading to higher concentration but lower yield. See section 2.4 for more information.*



## 6 Removal of residual ethanol and concentration

Incubate eluate with open lid at **90 °C** for **8 min** (2 × 10 µL elution) or **5 min** (10 µL elution).

*Note: For different elution volumes or incubation at 75 °C for non-denatured DNA see section 2.5 for detailed information.*



## 6 Appendix

### 6.1 Troubleshooting

Problem	Possible cause and suggestions
Low DNA yield	<p><i>Reagents not prepared properly</i></p> <ul style="list-style-type: none"> <li>Add the indicated volume of 96 – 100 % ethanol to the Buffer B5 Concentrate and mix well before use.</li> </ul>
No increase of PCR signal despite an increased volume of eluate used as template	<p><i>Residual ethanol in eluate</i></p> <ul style="list-style-type: none"> <li>Please see the detailed description of removal of residual traces of ethanol in section 2.5.</li> </ul> <p><i>Carry-over of chaotropic salts</i></p> <ul style="list-style-type: none"> <li>Perform a second washing step with Buffer B5 to remove last traces of Buffer NT.</li> </ul>
Discrepancy between $A_{260}$ quantification values and PCR quantification values	<p><i>Silica abrasion from the membrane</i></p> <ul style="list-style-type: none"> <li>Due to the typically low DNA content in very small samples and the resulting low total amount of isolated DNA, DNA quantification via <math>A_{260}</math> absorption measurement is often hampered by the low sensitivity of this method. When performing absorption measurements close to the detection limit of the photometer, the measurement may be influenced by minor amounts of silica abrasion. In order to prevent incorrect <math>A_{260}</math> quantification of small DNA amounts centrifuge the eluate for 30 s at <math>&gt; 11,000 \times g</math> and take an aliquot for measurement without disturbing any sediment. Alternatively, use a silica abrasion insensitive DNA quantification method (e.g., PicoGreen® fluorescent dye).</li> </ul>
$A_{260}/A_{280}$ ratio too high or too low	<p><i>Measurement not in the range of photometer detection limit</i></p> <ul style="list-style-type: none"> <li>In order to obtain a significant <math>A_{260}/A_{280}</math> ratio it is necessary that the initially measured <math>A_{260}</math> and <math>A_{280}</math> values are significantly above the detection limit of the photometer used. An <math>A_{280}</math> value close to the background noise of the photometer will cause unexpected <math>A_{260}/A_{280}</math> ratios.</li> </ul>

## 6.2 Ordering information

Product	REF	Pack of
NucleoSpin® gDNA Clean-up XS	740904.10	10 preps
	740904.50	50 preps
	740904.250	250 preps
NucleoSpin® gDNA Clean-up	740230.10	10 preps
	740230.50	50 preps
	740230.250	250 preps
Buffer NT	740614.100	100 mL
Buffer B5 (Concentrate) (for 100 mL Buffer B5)	740921	20 mL
Buffer BE	740306.100	100 mL
Collection Tubes (2 mL)	740600	1000

Visit [www.mn-net.com](http://www.mn-net.com) for more detailed product information.

### 6.3 Product use restriction / warranty

All MACHEREY-NAGEL products are designed for their intended use only. They are not intended to be used for any other purpose. The description of the intended use of the products can be found in the original MACHEREY-NAGEL product leaflets. Before using our products, please observe the instructions for use and the safety instructions from the respective Material Safety Data Sheet of the product.

This MACHEREY-NAGEL product is carrying documentation stating specifications and other technical information. MACHEREY-NAGEL warrants to meet the stated specifications. The provided warranty is limited to the data specifications and descriptions as given in the original MACHEREY-NAGEL literature. No other statements or representations, written or oral, by MACHEREY-NAGEL's employees, agents or representatives, except written statements signed by a duly authorized officer of MACHEREY-NAGEL are authorized. They should not be relied upon by the customer and are not a part of a contract of sale or of this warranty.

Liability for all possible damages that occur in any connection with our products is limited to the utmost minimum as stated in the general business terms and conditions of MACHEREY-NAGEL in their latest edition which can be taken from the company's website. MACHEREY-NAGEL does not assume any further warranty.


Products and their application are subject to change. Therefore, please contact our Technical Service Team for the latest information on MACHEREY-NAGEL products. You may also contact your local distributor for general scientific information. Descriptions in MACHEREY-NAGEL literature are provided for informational purposes only.

Last updated: 08/2022, Rev. 04

Please contact:  
MACHEREY-NAGEL GmbH & Co. KG  
Tel.: +49 24 21 969-333  
support@mn-net.com







Plasmid DNA

Clean up

RNA

DNA


Viral RNA and DNA

Protein

High throughput

Accessories

Auxiliary tools



[www.mn-net.com](http://www.mn-net.com)

**MACHEREY-NAGEL**



 <p><b>TÜV Rheinland</b> CERTIFIED</p>	<p>Management System EN ISO 13485:2016 ISO 9001:2015</p>	
	<p><a href="http://www.tuv.com">www.tuv.com</a> ID 0000056401</p>	

MACHEREY-NAGEL GmbH & Co. KG · Valencienner Str. 11 · 52355 Düren · Germany

DE +49 24 21 969-0 [info@mn-net.com](mailto:info@mn-net.com)

CH +41 62 388 55 00 [sales-ch@mn-net.com](mailto:sales-ch@mn-net.com)

FR +33 388 68 22 68 [sales-fr@mn-net.com](mailto:sales-fr@mn-net.com)

US +1 888 321 62 24 [sales-us@mn-net.com](mailto:sales-us@mn-net.com)